



Kit Components:

- (1) Heavy Duty Steering Stabilizer
- (1) Bolt
- (1) Nut
- (3) Flat Washers
- (1) Lock Washer
- (1) Tapered Insert
- (1) Straight Sleeve

Heavy Duty Steering Stabilizer

Part #: RT21008



Read all instructions carefully prior to starting installation.

1. Ensure all components are accounted for
2. Park vehicle on a flat, level surface.
3. Set the parking brake and chock the rear wheels.
4. Remove the steering stabilizer from the drag link and the axle.
Retain the axle side mounting bolt.
5. Install the **Straight Sleeve** into the end of the **Steering Stabilizer**.
6. Install the **Tapered Insert** into the hole in the drag link for the steering stabilizer. It is not necessary for this insert to sit flush with the drag link at this time.
7. Install the **Steering Stabilizer** onto the drag link using the **Bolt**, **Flat Washers**, **Lock Washer**, and **Nut**. Use the diagram to show the order of the hardware.
8. Install the **Steering Stabilizer** onto the axle using the factory bolt.
9. Torque the axle side steering stabilizer bolt to 55 ft. lbs.
10. Torque the drag link side steering stabilizer bolt to 45 ft. lbs.



While every attempt is made to ensure that the information contained in these instructions is correct, no liability can be accepted by the authors for loss, damage, or injury caused by any errors in, or omissions from the information given. All service should be performed by qualified mechanics. Crown Automotive Sales Co. Inc. cannot be held responsible for any mechanical work performed. Standard and accepted safety precautions should be used in every procedure.